


# BORE GAGE SETTER

- Used together with gage blocks to set bore gages

Code	Setting range
2395-400	18-400mm



2395-400

